

Stryker

800 & 9000 Series Cast Cutters

8126



8380-210



840



9003-210



848



[Armature / Field Assembly - CAST133](#)

[Armature Bearing Front - CAST026](#)

[Armature Bearing Rear - CAST027](#)

[Blades D001180, CAST037, CAST129](#)

[Blade Retaining Assembly - CAST114
\(CAST004, CAST005, CAST006\)](#)

[Brush - CAST023](#)

[Brush Cover \(800 Series\) - CAST022S](#)

[CAM - CAST003](#)

[Hood for 800 Series - CAST077S](#)

[Link Compatible - CAST008S](#)

[Mounting Post Bracket - CAST035](#)

[Oil Seal \(47-5\) - CAST029](#)

[On/Off Switch - CAST032](#)

[Pin for Pin Drive - CAST045](#)

[Pin Drive Compatible - CAST001S](#)

[Pin Drive Blade Lock Washer - CAST004S](#)

[Pin Drive Blade Spacer - CAST005S](#)

[Pin Drive Nut - CAST006S](#)

[Power Cord \(10 foot\) - CAST048S](#)

[Retaining Ring Internal - CAST074](#)

[Spacer Bushing - CAST021](#)

[Strain Relief Fitting - CAST007S](#)

[Strain Relief Spring - CAST070](#)

[Spring, Rear - CAST018](#)

[Wrench \(800 Series\) - CAST094](#)