

Stryker

940 Cast Cutters

940



Armature - CAST071
Bearing Front - CAST079
Bearing Rear - CAST080
Bearing Roller Kit (81-118,81-147)- CAST062
Bearing Cam (81-118) - CAST025

Blades

940-25 Equivalent - CAST075
940-35 Equivalent - CAST087
940-23 Equivalent - CAST088
Blade Guard (940-1-134)- CAST095S
Blade Retaining Screw Assembly - CAST086
Blade Screw Wrench (only for CAST086) - CAST130
Brush (870-1-13, 940-1-113& 38-49)- CAST023S
Brush Cap (58-18) - CAST063
CAM - CAST059
Fuse Power Supply - CAST096
Hood Screw & Lock-Washer - CAST142
Hood Screw with T-Handle Wrench - CAST097S
On/Off/Low Switch - CAST033
Output Drive Assembly (940-1-115, 940-1-118, 940-1-125) - CAST078
Rear Plug (940-1-35) - CAST144
Power Cable (sold by meter)- CAST060
Strain Relief - CAST085
Thermal Cut-off Protector - CAST050
Transistor - CAST036
Wrench for CAST086 - CAST130